

RAPIDUS WIRELESS NETWORKS

UPGRADING DEVICE


UPGRADE FRMWARE HOW-TO

UPGRADE


UPGRADE FIRMWARE HOW-TO

The following steps will detail the process of updating/upgrading your current firmware to the latest released firmware supported by Rapidus Wireless Networks. This manual shows the process on how to update the firmware on your device.


To begin your firmware update please go System > Maintenance.




You will be directed to the following page.




Under the “Flash new firmware image” section, click “Choose File” to select the new firmware that will be supplied by Rapidus Wireless Networks. **Be sure to check the “Keep settings” box, your device will default to factory settings if this box is not checked.** (The latest firmware updates will either be sent by email upon request or they can be downloaded from our website at www.rapiduswireless.com).




Select the most current firmware update that you have downloaded or have been supplied by from the Rapidus Wireless Networks support team.



Once you have selected our latest firmware update click “Flash Image”



You will be directed to the following page. Please click “Proceed” to finish your update.



You have now completed the process of updating your radio to our latest firmware. If you find you are having issues or the process is not configuring correctly contact us by phone at 855-864-9488 or visit our website www.rapiduswireless.com.